



INSERTION paddle wheel flowmeter for continuous flow measurement

- Economic integration in pipe systems without any additional piping
- 3-wire frequency pulse version to directly interface with PLC's (both PNP and NPN)
- Connection to Bürkert devices in remote versions



Type 8025



Type 8619 multiCELL Flow transmitter Transmitter/Controller

The paddle wheel flowmeter for continuous flow measurement is especially designed for use in neutral, slightly aggressive, solid free liquids.

The Bürkert designed fitting system ensures simple installation of the devices into all pipes from DN20 to DN400. The flowmeter produces a frequency pulse signal, proportional to the flow rate, which can easily be transmitted and processed by a Bürkert transmitter/controller.





Type 8611 Universal Controller eControl



PLC

Type 8802-GD TopControl system

General data Compatibility With fittings S020 (see corresponding data sheet) Materials Housing / Union nut PE / PC PA Cable plug Wetted parts materials Fitting Brass, stainless steel 1.4404/316L, PVC, PP, PVDF Sensor armature, paddle wheel **PVDF** Ceramics / FKM (EPDM option) Axis, bearing / Seal **Electrical connection** Cable plug **Connection cable** 1.5 mm² cross section; max. 50 m length, shielded Complete device data (fitting + electronic module) **Pipe diameter** DN20 to DN400 0.3 to 10 m/s Measuring range Medium temperature with fitting in 0 to 50°C (32 to 122°F) / 0 to 80°C (32 to 176°F) PVC / PP Stainless steel, brass, PVDF -15 to 80°C (5 to 212°F) PN10 (145.1 PSI) Medium pressure max. Viscosity / Pollution 300 cSt. max. / max. 1% (Size of particles 0.5 mm max.) Measurement error Teach-In ±1% of Reading¹⁾ (at the teach flow rate value) Standard K-factor $\pm 2.5\%$ of Reading^1) Linearity ±0.5% of FS.* Repeatability ±0.4% of Reading¹⁾ Environment -15 to 60°C (5 to 140°F) (operating and storage) Ambient temperature **Relative humidity** ≤ 80%, without condensation

* F.S. = Full scale (10 m/s)

¹⁾ Under reference conditions i.e. measuring fluid = water, ambient and water temperature = 20°C (68°F), applying the minimum inlet and outlet pipe straights, matched inside pipe dimensions

8020

bu	rkert

Electrical data					
Operating voltage	12 - 36 V DC (via Bürkert transmitter for "Low Power" version)				
Current consumption	with sensor				
Pulse version	≤ 50 mA				
Pulse "Low power" version	≤ 0.8 mA				
Output: Frequency					
Pulse version	Transistor NPN/PNP, open collector, max. 100 mA,				
	frequency: 0 300 Hz; duty cycle 1/2				
Pulse "Low Power" version	Transistor NPN, open collector, max. 10 mA,				
	frequency: 0 300 Hz; duty cycle 1/2				
Reversed polarity of DC	Protected				
Standards and approvals					
Protection class	IP65 with connector plugged-in and tightened				
Standard and directives					
EMC	EN 61000-6-2, 61000-6-3				
Pressure	Complying with article 3 of §3 from 97/23/CE directive.*				
Vibration	EN 60068-2-6				
Shock	EN 60068-2-27				

* For the 97/23/CE pressure directive, the device can only be used under following conditions (depend on max. pressure, pipe diameter and fluid).

Type of fluid	Conditions			
Fluid group 1, §1.3.a	DN 25 only			
Fluid group 2, §1.3.a	$DN \le 32$ or $DN > 32$ and $PN^*DN \le 1000$			
Fluid group 1, §1.3.b	$DN \le 25$ or $DN > 25$ and $PN^*DN \le 2000$			
Fluid group 2, §1.3.b	$DN \leq 400$			

Pressure / temperature chart







Design and principle of operation



The flowmeter 8020 consists of a transducer and a paddle-wheel with ceramic bearings. The ceramic rotating axis is set on the end of a PVDF INSERTION sensor armature. The transducer is mounted inside the armature. In a 3-wire system, the signal can be displayed or processed directly. The output signal is provided via cable plug.

When liquid flows through the pipe, the paddle-wheel is set in rotation. The non-wetted permanent magnets inserted in the paddle wheel generate a measuring signal which frequency is proportional to the flow velocity. A conversion coefficient (K-factor, available in the instruction manual of the fitting), specific to each pipe (size and material) enables the conversion of this frequency into flow rate.

Two electronic module versions with frequency output are available:

 with one pulse output (either NPN or PNP transistor output depending on wiring). An external power supply of 12 - 36 V DC is required. It is designed for connection to any system with open collector NPN or PNP frequency input. with one pulse "Low Power" output (NPN transistor output).
An external power supply of 12 - 36 V DC is required. Can only be connected to separate versions of flow transmitters Type 8025/8032.

Installation



The 8020 flowmeter can easily be installed into any Bürkert INSERTION fitting system Type S020, by just fixing the main nut. Minimum straight upstream and downstream distances must be observed. According to the pipe's design, necessary distances can be bigger or use a flow conditioner to obtain the best accuracy. For more information, please refer to EN ISO 5167-1.

EN ISO 5167-1 prescribes the straight inlet and outlet distances that must be complied with when installing fittings in pipe lines in order to achieve calm flow conditions. The most important layouts that could lead to turbulence in the flow are shown below, together with the associated prescribed minimum inlet and outlet distances. These ensure calm, problem-free measurement conditions at the measurement point.



The device can be installed into either horizontal or vertical pipes.



Pressure and temperature ratings must be respected according to the selected fitting material. The suitable pipe size is selected using the diagram Flow/ Velocity/DN. The measuring device is not designed for gas flow measurement.

burkert

Diagram Flow/Velocity/DN

Example:

• Flow: 10 m³/h

Ideal flow velocity: 2...3 m/s

For these specifications, the diagram indicates a pipe size of DN40 [or DN50 for (*) mentioned fittings]

Flow rate of fluid



• external threads acc. to SMS 1145

• weld ends acc. to SMS 3008, BS 4825/ASME BPE or DIN 11850 Series 2

Clamp acc. to SMS 3017/ISO 2852, BS 4825/ASME BPE or DIN 32676

Dimensions





Ordering chart for flowmeter Type 8020

A flowmeterType 8020 consists of:

- a flowmeter Type 8020 - an INSERTION fitting Type S020 (DN20 to DN400 - Refer to corresponding data sheet - has to be ordered separately)

Description	Operating voltage	Output	Sensor version	Electrical connection	Item no.
Pulse version flowmeter (pluggable to Types 8025 Uni-	12 - 36 V DC	Frequency with pulse,	short	Cable plug	419 587
versal transmitter, batch controller or konti-Dos; 8032; PLC)		PNP or NPN	long	Cable plug	419 589
Pulse "Low Power" version flowmeter (plug-	wmeter (plug- from associated	m associated Frequency with pulse, transmitter NPN	short	Cable plug	419 591
gable to Types 8025, 8032 transmitter)	transmitter		long	Cable plug	419 593

Ordering chart for accessories (has to be ordered separately)

Specifica- tions	ltem no.
Set with 1 green FKM and 1 black EPDM gasket	552 111
Ring	619 205
Union nut	619 204
Cable plug with cable gland (Type 2508)	438 811
Cable plug with NPT1/2 " reduction without cable gland (Type 2509)	162 673

Interconnection possibilities with other Bürkert products



In case of special application conditions, please consult for advice.

Subject to alteration. © Christian Bürkert GmbH & Co. KG

1407/11_EU-en_00891773